

Two link serial chain paper robot.

W.S.Harwin, U. Reading Jan 2008

Cut out the two links. Use the inside of a biro to roll up the link and selotape. Upturn drawing pins can be used to form the joints (be careful).

